



Nød Checkliste

Cessna 172

Motorstop

Glidehastighed.....	80mph/70kts
Karburatorforvarme	Tænd
Tankvælger.....	Begge
Blandingshåndtag.....	Fuld fed
Magneter	Check/Begge
Primer	Låst

Før nødlanding

Glidehastighed.....	80mph/70kts
Landingsområde	Vælg
Mayday call/Transponder	Udfør/7700
Pax	Brief
Redningsveste	Efter behov
Flaps.....	Efter behov
<i>Når landing er sikret el. tiden tillader det</i>	
Tankvælger.....	Lukket
Blandingshåndtag.....	Helt mager
Gashåndtag	Helt lukket
Magneter	Slukket
Hovedkontakt.....	Slukket
Døre.....	Lås op
Finale hastighed	75mph/65kts

Motorbrand på jorden

Tankvælger.....	Lukket
Gashåndtag	Fuld gas
Magneter	Start
<i>(Start ikke hvis motoren kører allerede)</i>	
Evakuér & ildslukker	Udfør/Brug

Motorbrand i luften

Blandingshåndtag.....	Helt mager
Tankvælger.....	Lukket
Hovedkontakt.....	Sluk
Kabinevarme & luft	Lukket
Dyk med	120mph/105kts
Hovedkontakt	Tænd evt.
Når ilden slukker.....	Før nødlanding

Elektrisk brand

Hovedkontakt.....	Sluk
Elektrisk udstyr	Sluk
Kabine varme & luft	Luk
<i>Sluk branden</i>	
Hovedkontakt.....	Tænd
Sikringer	Check
Nødvendigt udstyr	Tænd
Kabineluft.....	Åben
<i>Land på nærmest egnede flyveplads</i>	

IKAROS FLY APS
130,85 MHz

Emergency Checkliste

Cessna 172

Engine failure

Airspeed	80mph/70kts
Carburator heat	On
Fuel selector.....	Both
Mixture.....	Rich
Magneto.....	Check/Both
Primer	Locked

Emergency landing

Airspeed	80mph/70kts
Landing area	Select
Mayday call/Transponder	Perform/7700
Pax	Brief
Life jackets	Don
Flaps.....	As required
<i>When landing assured or time permits</i>	
Fuel selector.....	Off
Mixture.....	I.C.O.
Throttle	Idle
Magneto.....	Off
Master	Off
Doors.....	Unlatch
Final speed.....	75mph/65kts

Engine fire on ground

Fuel selector.....	Off
Throttle	Full forward
Magneto.....	Crank engine
<i>(Do not crank if engine is already running)</i>	
Evacuate & Fire extinguisher	Perform/Use

Engine fire in the air

Mixture.....	I.C.O.
Fuel selector.....	Off
Master switch	Off
Cabin heat & air.....	Off
Dive speed	120mph/105kts
Master switch	On if req.
When fire stops	Emergency ldg.

Electrical fire

Master switch	Off
Electrical equipment	Off
Cabin heat & air.....	Off
<i>Extinguish the fire</i>	
Master switch	On
Circuit breakers	Check
Necessary equipment.....	On
Cabin air	Open
<i>Land on nearest suitable airport</i>	

IKAROS FLY APS
130,85 MHz